

PERSONAL VIDEO RECORDING (PVR) INSTRUCTIONS

Accessing your PVR

After pressing "MENU" on your remote control, choose "PVR" from the main TV menu to manage your Personal Video Recordings.



From this menu, you can do the following:

- ⇒ **Recordings**: view your recordings.
- ⇒ **To Record**: view what you have scheduled to record.
- ⇒ **Schedule Priority**: when multiple shows air at the same time, you can schedule your favorites to take priority.
- ⇒ **Schedule Event**: record at a specific time, regardless of what's playing.
- ⇒ **Record History**: shows previous recorded programs.



Playing Back Recordings

Once you have recorded your favorite shows, you can keep them for as long as you like and play them back when ever you choose.

When you view a particular show, you have the following options:

1. Start watching the show from the beginning.
2. Resume watching the show from where you previously stopped.
3. Lock the recorded show from being unintentionally deleted.
4. Delete the recording to make room for other shows to be recorded. (Remember there is no limit to the number of shows you can record. Just the combined length of the programs you have chosen to save.)




What's Scheduled to Record

It's easy to see what you've already chosen to record, while viewing the Program Guide. A **single red** dot indicates a one time recording, while a **double red** dot shows that you've chosen to record a series. When you see the **star** ★ next to a program, this indicates a new series program.



Schedule Priority

There may be times when two or more shows scheduled to be recorded happen to air at the same time. By placing your most desired shows at the top of this list, you can ensure they are recorded instead of one lower on the list.



Series Recording Options

By choosing "Edit Series Recording: for a particular show, you can tailor your options to ensure you record exactly what you want.



Channels allows you to limit this series to a particular channel or you can allow the recording to occur on any channel you're subscribed to.

Preference will ensure your recording is set for High Definition channels when available.

Episodes can filter out re-runs so that only new episodes are recorded.

Pad In and Pad Out lets you force the recording to begin a few minutes before (Pad In) the scheduled show time or to keep recording (Pad Out) a few minutes after the show should have finished.

Limit to helps you manage the storage space on your PVR system by letting you choose to record 1, 5, 10 or ALL episodes for that series.



**PERSONAL VIDEO
RECORDER (PVR)
SERVICE**

**980 North Front Street
PO Box 19
North Liberty, IA 52317**

**Phone: (319) 857-4535
24-Hour Repair Service:
(319) 857-4535
Fax: (319) 857-4001**

www.swishertelephone.com

**Office Hours:
Monday-Friday
8 a.m.—4:30 p.m.**